

The Care and Handling of MetalPrints

Congratulations!

You are now the proud owner of a MetalPrint, one of the most cutting-edge photo print substrates on the market. We know you will enjoy your print for years to come.

Handling:

For MetalPrints with foam *Float Mounts*, please make sure to **remove all tape** securing the print to the box, so that the print is not bent when you remove it from the box.

For MetalPrints with *Flush or Inset Frames*, please be careful **not to twist the frame** when removing the print from the box or crate. After cutting the plastic strapping bands, lift one side straight up and rest the print gently along the other edge, carefully removing any foam packing strips.

Careful not to drop or bump edges or corners.

.....

Hanging:

Framed MetalPrints can be hung using the wire hanger provided or directly from the inside edge of the frame with a wall hook.

Be sure that your wall hooks are of appropriate strength for the frame so the print does not fall. You may want to install wall anchors or other secure hanging devices.

.....

Care:

MetalPrints can be cleaned using a soft cloth or towel (*avoid scratchy paper towels*). If necessary, you can use water or window cleaner (*like Windex*) to remove fingerprints or dust.

Thanks, we hope you enjoy it!